

E7CP – NATURAL OILED WOOD FLOORS

To correctly care for your flooring you will need:

1 x DC Breakframe Flat Mop (40cm) Cleaning Kit inc. handle A026

1 x Element 7 AE Detergent 1L E7002

for your convenience we also have available for purchase:

1 x DC Bucket and Wringer (or 2 buckets)

Everyday cleaning can be done using a vacuum cleaner. Make sure the head brushes are out. Alternatively sweep with a brush.

Remove food spills and obvious dirt as soon as possible with a damp, not soaking, cloth.

Regular cleaners:- E7 AE Detergent is a light cleaning fluid recommended to be used once a month, but no more than a maximum of once a week. Shake thoroughly and mix 20ml (2% or 1 capful) of detergent per litre of warm water. Use the DC Breakframe Mop, which has a cotton head. Keep your soap solution in one bucket. Soak the cotton head in this bucket and wring out the excess water back into it. Have a second bucket with warm water. After every pass with the mop, rinse out the dirty head in this warm water (bucket 2) before soaking it once again in the mixed soap solution (bucket 1). Let the soap solution dry into the surface when you finish, do not rinse the floor, the soap leaves a protective film.

Scratches:- Woca Maintenance oil natural If you see a scratch in the floor surface then use your finger-tip or a cotton rag to apply a fraction of oil into it. Do not treat the whole board. Remove any excess oil around the scratch with a cloth (dispose of the cloth externally having soaked it in water immediately after use).

Mechanical damage and heavy scratches:- should be professionally repaired by a French polisher.

Future Maintenance:- Recommended for residential floors every one to three years depending on use. **Option 1: Reoiling E7CP Natural oil & E7CP Veneto Wax.** This should be undertaken professionally.

Option 2: (Matt finish) Linea LinfoOpax/opr 2111 or (Satin finish) Linea LinfoLegno or (gloss finish) Linea LinfoLegno Supergloss.
These can be applied manually.

DANECARE supply the above cleaning equipment and products.
They should also be contacted for French Polishing and all your future floor maintenance requirements.

01952 727899

shop@danecare.co.uk

ref: DC049

Dane Care Break Frame Assembly Instructions

1. Assemble the handle:

Insert one of the chrome poles inside the other one. The drilled holes should NOT be at the join.



2. Join the handle to the Breakframe

Slide the blue plastic clip out of the Breakframe neck.

Push the handle into the neck, line up the holes and put the clip back in. We found this fiddly 1st time, so dont force anything. Tighten the screw-neck.



3. Attach the looped cotton mop head

Fold the breakframe in half by pushing down on the pedal so that you have some slack to work with. Loosen the two grey clips on each side and slide the blue tabs of the mop head through the gap ie. underneath the clip. Line up the holes in the blue tab with the two pins on the clip and then press it down.



When flattened again your mop head should appear as such:



Instructions bespoke to your floor for the cleaning and aftercare should have been forwarded to you by email directly or via your construction manager.

Should you not have received these please contact them or Dane Care's helpline on 01952 727899.

It will be our pleasure to advise on how to maintain the beauty of your new floor.

Cleaning kits don't include buckets as not all floors and layouts are suitable. However, you may well find this a useful purchase; delivered c. £65 from www.danecashop.co.uk

DC Premium Breakframe Bucket and Wringer assembly Instructions

1. Buckets should be delivered with the wheels in.

Check these are firmly installed.



2. The parts for your bucket should appear as in this picture, although the wheels will have been installed for you.



Step 1: slide the thin, blue divider down into the middle of the bucket to separate the two sides.

3. Attach the silver-metal arm to the wringer by removing the black clip, pushing arm in, lining up holes and putting clip back in.



4. Hook the wringer over the flat side of the bucket.

Use the front section for fresh cleaning fluid. The rear section will collect dirty water as the mop is wrung out.



Instructions bespoke to your floor for the cleaning and aftercare should have been forwarded to you by email directly or via your construction manager.

Should you not have received these please contact our helpline on 01952 727899.

It will be our pleasure to advise on how to maintain the beauty of your new floor.