



1 PREPARE 2 TREAT 3 MAINTAIN

MASTER BASE PRIMER, NATURAL

PRODUCT DESCRIPTION

Master Base Primer, Natural is a water-based, quick-drying and sandable wood primer. It seals the wood and minimises tannic acid penetration and side-bonding. It can be used for all untreated or sanded surfaces. Master Base Primer, Natural works

as a powerful base layer before treatment with other water-based WOCA floor lacquers.

APPLICATION AREA

Lacquering of new, untreated and sanded wood. Ideal for all species of wood.



120 min

Quick-drying

Sandable after approx. 120 min. at 20°C and 30-60% RH.



use

Economical in use

Very quick, easy and economical to use. Water-based.



side-bondings

Reduces side-bondings

Reduces the risk of side-bondings due to a high flexibility. Minimizes penetration of tannic acid.



Product information

Coverage: 10-12 m²/L

Packaging: 5 L





WORK DESCRIPTION

Preparation

It is important that both wood and product have a temperature of min. 15°C (preferably around 20°C) and air humidity of approximately 40-60 %. Make sure that the room is well-ventilated for optimal evaporation and drying time.

Untreated floors must be free of dirt, grease, wax and dust. Floors that have been lacquered previously must be sanded down to clean wood before the primer is applied. Vacuum thoroughly and wipe the floor down afterwards if necessary, using a tightly-wrung water-soaked cloth. Shake the Master Base Primer thoroughly before use.

Note

If drying times are not followed, this can result in poor adhesion and reduced resistance. For each layer of Master Base Primer, drying times will be increased. High temperature and low air humidity will reduce drying times. Low temperature and high air humidity will extend drying times.



APPLY

TREATMENT

- 1 Untreated or sanded surfaces:**
Final sanding must be done with fine sandpaper (grit 120). Vacuum carefully and wipe surface with a cloth hard wrung in clean water. Apply Master Base Primer, Natural undiluted with brush or roller and allow the surface to dry. Apply a layer of topcoat with one of the WOCA floor lacquers and sand between coats using grit 150–200 sandpaper. Vacuum carefully and apply another 1-2 topcoats.
- 2 Relacquering already lacquered surfaces:**
Master Base Primer, Natural is only suitable for the priming of untreated or sanded surfaces.