DC Premium Breakframe Bucket and Wringer assembly Instructions

For simplifying the cleaning of open-plan flooring areas—www.aboutwoca.co.uk
For an instruction video www.vimeo.com/800094259

- 1.Buckets are delivered without the wheels in so these need to be placed into place firmly. Then turn the bucket onto all four wheels and apply a final strong push to click them into position. Check these are installed equally into the fitting.
- 2. The parts for your bucket should appear as in this picture, although the wheels will have been installed for you.

Step 1: slide the thin, blue divider down into the middle of the bucket to separate the two sides. This isn't intended to be watertight, but stops immediate dilution from the dirty (wringing side) to the cleaner (soa-solution side).

3. Attach the silver-metal arm to the wringer by removing the black clip, pushing arm in, lining up holes and putting clip back in.







4. Hook the wringer over the flat side of the bucket.






Instructions bespoke to your floor for the cleaning and aftercare should have been forwarded to you by email directly or via your construction manager.

Should you not have received these please contact our helpline on 01952 727899. It will be our pleasure to advise on how to maintain the beauty of your new floor.

Using the Bucket and Wringer

- 1. Put your chosen cleaning solution into the open side of the bucket
- 2. Break open the mop and frame so it is in a folded position dip it into the clean solution







4. Put mop on floor and lock flat ready for use - mop the floor.



- 5. For best results, clean an area of flooring c 5m2. Then break open the mop and dunk it into the cleaning solution before squeezing it out. This serves to flush dirt out of the mop. THEN REPEAT the process of dunking the mop and squeezing it before you carry on with cleaning.
- 6. At the end of the process the mop head can be removed and washed in a washing machine. If you are doing very large areas you may like to have more than one mop head since grime can accumulate in the mop head as your proceed.

Instructions bespoke to your floor for the cleaning and aftercare should have been forwarded to you by email directly or via your construction manager.

Should you not have received these please contact Dane Care Ltd on 01952 727899.

It will be our pleasure to instruct and advise on how to maintain the beauty and quality of your new floor.

Alternatively visit www.danecareshop.co.uk to view our online content.